

XRAY X4'24'

- 80% brake
- 0% autobrake
- *Body position measured from the deep groove in front of the window (not the window line!)
- *most drivers preferred 3mm bumpsteer to make the turn-in more calm
- *For new tracklayouts begin with more toe-in and maybe without PSS, as this will be easier to drive

FRONT BOTTOM VIEW

STEER. LOCK
23 /degr.

T-BRACE
ALU ☐
BRASS ☐

FR **RE**
SERVO HOLDER

MOTOR MOUNT

CHASSIS T-BRACE

FRONT ARMS
MEDIUM ☐
HARD ☒

CHASSIS
GRAPHITE ☐
ALU ☒
ALU 1.5mm ☐

REAR ARMS
MEDIUM ☐
HARD ☒