

**XRAY X4'23**

COMMENTS

Clean tires with Wurth before applying additive.

The diagram illustrates the assembly options for the robot chassis from three perspectives: Front, Bottom View, and Rear.

**FRONT VIEW:**

- STEER. LOCK:** 25 /degr.
- STEER. SHIM:** SIZE 7.5 /mm
- FRONT BRACE:** YES ☐ NO ☒
- SERVO HOLDER:** FR ☒ RE ☐
- FRONT ARMS:** MEDIUM ☐ HARD ☒

**BOTTOM VIEW:**

- MOTOR MOUNT:** Graphite ☐ ALU ☐ ALU FLEX ☒

**REAR VIEW:**

- T-BRACE:** ALU ☐ BRASS ☐
- CHASSIS T-BRACE:** (Indicated by a line pointing to the chassis)
- REAR ARMS:** MEDIUM ☐ HARD ☒