

**XRAY X4'24'**

When the track temp. drop, put 2nd and 3rd screws on the t-brace instead of 1st and 2nd.

**FRONT BOTTOM VIEW REAR**

**STEER. LOCK**  
26 /degr.

**FR RE**  
**SERVO HOLDER**

**MOTOR MOUNT**

**CHASSIS T-BRACE**

**FRONT ARMS**  
MEDIUM ☐  
HARD ☒

**CHASSIS**  
GRAPHITE ☒  
ALU ☐  
ALU 1.5mm ☐

**T-BRACE**  
ALU ☒  
BRASS ☐

**REAR ARMS**  
MEDIUM ☐  
HARD ☒