

**XRAY X4'23**

### FRONT

**FRONT CASTER**

5° 4° 3°

Adjust with eccentric bushings

**UPPER CLAMP**

STD. ☐ ☒ -1.5mm

**BUMP STEER**

3 /mm

**HEIGHT**

/mm

**SHIM**

/mm

2 /mm **FF**

5.2 /mm **FR**

**RIDE HEIGHT**

2 /mm **FR**

**SERVO SAVER**

**SERVO HORN**

### REAR

**REAR CASTER**

0.5° 1.5° 2.5° 3.5° 4.5° 5.5°

Adjust with eccentric bushings

**UPPER CLAMP**

STD. ☐ ☒ -1.5mm

**TOE GAIN**

5 /mm

2.5 /mm **RF**

5.4 /mm **RR**

**RIDE HEIGHT**

2 /deg. **CAMBER**

Left=Right

**DRIVE SHAFT**

58mm 59mm **BEARING** ☒ **BLADE**

**FRONT SUSPENSION**

**FRONT BRACE**

YES ☐ NO ☒

**BULKHEAD SHIMS**

YES ☒ 3mm ☐ NO

**FRONT SHOCK POSITION**

1 2

**FRONT HUB**

HARD ☐

GRAPHITE ☐

ALU ☐

**SHIM**

0.5 /mm

**DOWNSTOP**

6.6 /mm

2 /deg. **CAMBER**

Left=Right

**DRIVE SHAFT**

52mm 54mm **BEARING** ☒ **BLADE**

**REAR SUSPENSION**

**REAR SHOCK POSITION**

1 2

**REAR HUB**

HARD ☐

GRAPHITE ☐

ALU ☐

**SHIM**

1 /mm

**DOWNSTOP**

4 /mm

1 **TOE OUT**

Left=Right

**DIFF POSITION**

UP ☐ DOWN ☒

**UPPER ARM**

SOFT ☒

MEDIUM STD. ☐

**HUB OFFSET**

STD. ☒ -0.5mm ☐ +0.5mm **SHIM**/mm

**FRONT TOP VIEW**

**ACKERMANN**

SHIM 0.5 /mm

**STEERING BRIDGE**

YES ☐ NO ☐

**STEERING PLATE**

8.0mm ☒ STD. ☐

7.5mm ☐

1.75 **TOE IN**

Left=Right

**DIFF POSITION**

UP ☐ DOWN ☒

**UPPER ARM**

SOFT ☐

MEDIUM STD. ☒

**HUB OFFSET**

STD. ☒ -0.5mm ☐ +0.5mm **SHIM**/mm

**REAR TOP VIEW**

**SHIM**

0 /mm

**FRONT BOTTOM VIEW**

**STEER. LOCK**

25 /deg.

**STEER. SHIM**

SIZE /mm

**FRONT BRACE**

YES ☐ NO ☐

**FRONT ARMS**

MEDIUM ☐

HARD ☒

**REAR BOTTOM VIEW**

**T-BRACE**

ALU ☐

BRASS ☐

**REAR ARMS**

MEDIUM ☐

HARD ☒