

**XRAY X4'23**

### FRONT

**FRONT CASTER**

5° ☐ 4° ☒ 3° ☐

Adjust with eccentric bushings

**UPPER CLAMP**

STD. ☒ ☐ -1.5mm

**BUMP STEER**

4 /mm

**HEIGHT**

/mm

**SHIM**

6 /mm

2.5 /mm **FF**

5.2 /mm **FR**

**RIDE HEIGHT**

☐ **SERVO SAVER**

☒ **SERVO HORN**

### REAR

**REAR CASTER**

0.5° ☐ 1.5° ☒ 2.5° ☐ 3.5° ☐ 4.5° ☐ 5.5° ☐

Adjust with eccentric bushings

**UPPER CLAMP**

STD. ☒ ☐ -1.5mm

**TOE GAIN**

5 /mm

**RF**

3 /mm

**RR**

3 /mm

**RIDE HEIGHT**

### FRONT SUSPENSION

2 /degr. **CAMBER**

Left = Right

**BODY STOP**

YES ☐ ☒ NO

/mm

**FRONT BRACE**

YES ☐ ☒ NO

**BULKHEAD SHIMS**

YES ☒ 3mm ☐ NO

**DRIVE SHAFT**

☒ 58mm ☐ 59mm

☒ **BEARING** ☐ **BLADE**

1.5 /mm **SHIM**

2 /mm

**FRONT SHOCK POSITION**

2

**FRONT HUB**

HARD ☐

GRAPHITE ☒

ALU ☐

**SHIM**

0.5 /mm

**DOWNSTOP**

6 /mm

#107702 Chassis Droop Gauge Blocks #107712 Chassis Droop Gauge

### REAR SUSPENSION

2 /degr. **CAMBER**

Left = Right

**BODY POST**

VERTICAL ☐

HORIZONTAL ☒

**DRIVE SHAFT**

☐ 52mm ☒ 54mm

☒ **BEARING** ☐ **BLADE**

1 /mm **SHIM**

2 /mm

**REAR SHOCK POSITION**

2

**REAR HUB**

HARD ☐

GRAPHITE ☒

ALU ☐

**SHIM**

1 /mm

**DOWNSTOP**

5 /mm

#107702 Chassis Droop Gauge Blocks #107712 Chassis Droop Gauge

### FRONT TOP VIEW

1 **TOE OUT**

Left = Right

**ACKERMANN**

SHIM 0 /mm

**DIFF POSITION**

UP ☐

DOWN ☒

**UPPER ARM**

SOFT ☐

MEDIUM STD. ☒

**HUB OFFSET**

STD. ☒ -0.5mm ☐ +0.5mm

SHIM/mm

3 **TOE IN**

Left = Right

**SHIM**

2 /mm

**BRASS WEIGHT FOR MOTOR MOUNT**

**STEERING PLATE**

8.0mm ☒ STD.

7.5mm ☐

**STEERING BRIDGE**

YES ☐ ☒ NO

**DIFF POSITION**

UP ☐

DOWN ☒

**UPPER ARM**

SOFT ☐

MEDIUM STD. ☒

**HUB OFFSET**

STD. ☐ -0.5mm ☒ +0.5mm

SHIM/mm

### FRONT BOTTOM VIEW

**STEER. LOCK**

27 /degr.

**STEER. SHIM**

SIZE 9 /mm

**FRONT BRACE**

YES ☐ ☒ NO

**SERVO HOLDER**

FR ☐ RE ☐

**FRONT ARMS**

MEDIUM ☐

HARD ☒

**T-BRACE**

ALU ☐

BRASS ☐

**MOTOR MOUNT**

**CHASSIS**

GRAPHITE ☐

ALU ☒

ALU FLEX ☐

**REAR ARMS**

MEDIUM ☐

HARD ☒