

VER.01 ©XRAY

**FRONT & REAR SUSPENSION**

### FRONT CASTER

<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>
5°	4°	3°

Adjust with eccentric bushings

**BUMP STEER**  
2 /mm  
☒

**HEIGHT**  
/mm  
☐

**SHIM**  
3 /mm  
☐

**FF**  
2 /mm  
☒

**RIDE HEIGHT**  
5.2 /mm  
☒

**FR**  
2 /mm  
☒

☐ SERVO SAVER  
☒ SERVO HORN

### REAR CASTER

<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>
0.5°	1.5°	2.5°

Adjust with eccentric bushings

**TOE GAIN**  
4 /mm  
☐

**RR**  
2.5 /mm  
☒

**RF**  
2.5 /mm  
☒

**RIDE HEIGHT**  
5.4 /mm  
☒

---

### FRONT CAMBER

Left = Right

2 /deg.

**BODY STOP**  
YES ☒ NO ☐  
29 /mm

**FRONT BRACE**  
YES ☐ NO ☒

**BULKHEAD SHIMS**  
YES ☒ 3mm NO ☐

**DRIVE SHAFT**  
☒ 58mm ☐ 59mm  
☒ STD. BEARING ☐

**DOWNSTOP**  
6.0 /mm

### FRONT HUB

COMPOSITE ☒  
ALU ☐

SHIM 0.5 /mm

HUDY 0 1 2 3 4 5 6 7 8 9 10

#107702 Chassis Droop Gauge Blocks #107712 Chassis Droop Gauge

---

### REAR CAMBER

Left = Right

1 /deg.

**REAR SHOCK POSITION**  
1 2 3 4

**REAR HUB**  
COMPOSITE ☒  
ALU ☐

**SHIM**  
1.5 /mm

HUDY 0 1 2 3 4 5 6 7 8 9 10

#107702 Chassis Droop Gauge Blocks #107712 Chassis Droop Gauge

### REAR DOWNSTOP

4.0 /mm

---

### FRONT TOP VIEW

Left = Right

1 TOE OUT

ACKERMANN SHIM /mm

DIFF POSITION UP ☒ DOWN ☐

UPPER ARM STANDARD ☐ Soft ☒

OFFSET STANDARD ☐ -0.5mm ☒ SHIM/mm

STEERING BRIDGE YES ☒ NO ☐

TOP DECK SPLITTED ☐ TOP DECK FLEX ☒ TOP DECK CUTTING ☐

### REAR TOP VIEW

Left = Right

2 TOE IN

UPPER ARM STANDARD ☐ Soft ☒

OFFSET STANDARD ☒ -0.5mm ☐ SHIM/mm

---

### FRONT BOTTOM VIEW

STEER. LOCK 22 /deg.  
STEER. SHIM SIZE 13 /mm

FRONT BRACE YES ☐ NO ☒

FRONT ARMS MEDIUM ☒ HARD ☐

STEER. PLATE STANDARD ☒

### REAR BOTTOM VIEW

T-BRACE ALU ☐ BRASS ☐

MOTOR MOUNT

CHASSIS T-BRACE

CHASSIS GRAPHITE ☒

REAR ARMS MEDIUM ☒ HARD ☐